Display

OFF-ON Switch

W/PRGM-RUN Switch

Window

Program Control Keys

Gold Prefix Keys

Blue Prefix Key

Arithmetic Keys

Before using the calculator, you may need to charge its battery pack as described in appendix A. The calculator can then be operated while the battery is charging or, later, on battery power alone.

Your
the w
operat
model
to pro

Thre

You c
1. 7
2. 7
3. 3

1. To

Figure
most ev
primar
tions a
face,

N
th
p
b

To exec
then the
alternat
associat
ment) c
then the
ample: